



MERLIN[®]
Communications System

Administration Manual:
Models 1030 and 3070
With Feature Module 3




Table of Contents

	Page
How to Use This Manual	2
Administration Overview	3
MERLIN System Components	6
The Model 1030 Control Unit and Expansion Unit	6
Model 1030 Control Unit	7
Model 3070 Control Unit	8
The Administrator/Attendant Console	10
Using the Console	10
Optional Equipment	11
Preparing to Administer Your System	14
The Forms and Labels You Need	15
Choosing a Time to Administer Your System	15
Administration Mode	16
Entering and Leaving Administration Mode	16
Basic Administration	17
Setting Your Control Unit	18
Specifying Touch-Tone or Rotary Dialing	19
Assigning Lines and Call Restrictions to Voice Terminals	20
Assigning Primary Lines	20
Assigning Secondary Lines and Call Restrictions	20
Assigning PBX/Centrex Extensions to Line Buttons	22
Administering Fixed Feature Buttons	23
Customizing with Additional System Options	24
Assigning Call Coverage Permissions	25
Assigning Call Pickup Permissions	26
Blocking the System from Incoming Calls	27
Programming Voice Terminals for Office Priorities	28
Assigning an Automatic Line Selection Sequence	30
Assigning Programmable Line Ringing for Incoming Calls	31
Assigning Cover Buttons	32
Programming Voice Terminals for Personal Priorities	34
Assigning Features to Programmable Buttons	35
Feature Programming Chart	36
Assigning Personal Speed Dial Codes to 5- and 10-Button Voice Terminals	38
Using Special Characters in Programmed Dialing Sequences	39
Selecting a Personalized Ring	41
Programming Voice Announcement Disable	42
Special Information about Attendant Consoles	43
Attendant Console Programming Tips	43
Special Information about 34-Button Voice Terminals	46
34-Button Voice Terminal Programming Tips	46
Special Information about 10-Button Voice Terminals	47
10-Button Voice Terminal Programming Tips	47
Special Information about 5-Button Voice Terminals	48
5-Button Voice Terminal Programming Tips	48
Special Information about Basic Telephones	48
MERLIN System Features	49
Appendix: System and Voice Terminal Configuration Forms	56
Index	65
Quick Reference Guide to Administration Procedures	67

How to Use This Manual

The advanced technology of the MERLIN™ communications system offers a flexibility that allows you to customize the system to your business communication needs. As system administrator, you may be responsible for customizing your MERLIN system immediately after installation, and you will undoubtedly be the person to make any necessary changes as your business needs change.

This administration manual takes you step by step through the procedures involved in customizing your system. Here is how to use it:

If you are setting up a new system for the first time

1. Read the "Administration Overview" page 3, to learn about the tasks you'll be performing as system administrator.
2. Review the "MERLIN System Components," page 6, to become familiar with the equipment you'll be working with.
3. If you haven't already decided which features you want your MERLIN system to have, look through the "MERLIN System Features" described on pages 49 through 55.
4. Get ready to administer your system by following the instructions in "Preparing to Administer Your System," page 14.
5. Read through "Basic Administration" page 17, and perform those tasks that apply to your particular system.
6. Work your way through "Customizing with Additional System Options" page 24, adding features that fit your needs.
7. If you want some voice terminals to have features that affect how other voice terminals operate (such as Cover buttons), oversee the programming of those features as suggested in "Programming Voice Terminals for Office Priorities" page 28.
8. If you choose, further customize features on individual voice terminals by performing the procedures described in "Programming Voice Terminals for Personal Priorities," page 34.
9. To learn how to program your attendant console(s), review "Special Information about Attendant Consoles," page 43.
10. If you have many 5-button voice terminals connected to your system, read "Special Information about 5-Button Voice Terminals," page 48.



If you are changing some options or features that are already in place

1. Review the information in "Preparing to Administer Your System," page 14.
2. Using the Table of Contents, Index, or page references in "MERLIN System Features," pages 49 through 55, locate the procedure for the option or feature you want to change and perform the necessary steps in the procedure.

ADMINISTRATION OVERVIEW

Because the effects of system administration are wide-ranging, only you or someone you delegate should perform administration procedures. The term *administer* as used in this manual refers to the act of establishing certain options and features that have systemwide impact, such as assigning the lines that each voice terminal can access or determining who can cover calls for whom. Before you can perform administration, you have to put the system in a special state of operation, called administration mode. (See "Administration Mode," page 16, for more information about this operating state.) In contrast, the term *program* refers to assigning features to an individual voice terminal from the voice terminal itself. Anyone can put a voice terminal in programming mode and assign it features at any time without entering administration mode.

System administration involves a series of simple procedures that you perform at the control unit and at the administrator/attendant console (the voice terminal connected to the intercom 10 jack on the control unit). The MERLIN system is designed to be up and running with a minimum amount of administration. However, depending on the conditions of your communications environment or the options you choose, certain administration procedures may be *required* to set up a newly installed system. Before attempting any other procedures, you must review the information in "Basic Administration," page 17, and complete the procedures that apply to your system and business needs. Most administration procedures however are optional, depending on which features you want to use in your business; these features are described in "Customizing with Additional System Options," page 24.



There are some features that you may want to assign to certain voice terminals yourself because they influence call-handling efficiency throughout your entire business; these are described in "Programming Voice Terminals for Office Priorities," page 28. They do not involve administration procedures, but rather, simple programming at individual voice terminals. Finally, if you want to help people program their voice terminals to meet their individual needs, follow the procedures outlined in "Programming Voice Terminals for Personal Priorities," page 34. Later, if your needs change, you can always alter any system administration or programming that has been done.

The chart on the following page shows the types of procedures described in this manual. If you are about to perform system administration for the first time, be sure to read "Preparing to Administer Your System," page 14, before you attempt any procedures.

Once you've completed system administration, your MERLIN system and your PBX/Centrex system work together, so you can use all of your PBX/Centrex features as well as the innovative features of the MERLIN system's advanced technology. However, you may have to follow new procedures to use some familiar features. For example, when a PBX/Centrex feature requires a switchhook flash, touch **Recall** instead of pressing the switchhook.

Prepare for System Administration

These procedures help you get ready to administer your system.

- Fill out System Configuration Forms.
- Select a time to administer your system.
- Review how to enter and leave administration mode.

Perform Basic Administration

These procedures may be required just after the system is installed. Perform them at the control unit and the administrator/attendant console.

- Set your control unit.
- Specify Touch-Tone or rotary dialing.
- Assign lines and call restrictions to voice terminals.
- Assign PBX/Centrex extensions to line buttons.
- Administer fixed feature buttons.

Customize with Additional Custom Options

These procedures are optional. Perform them at the administrator/attendant console.

- Assign Call Coverage permissions.
- Assign Call Pickup permissions.
- Block the system from incoming calls.

Program Voice Terminals for Office Priorities

These procedures are optional. Perform them at individual voice terminals whenever you want to give someone access to these features.

- Assign an Automatic Line Selection sequence.
- Assign Programmable Line Ringing for incoming calls.
- Assign Cover buttons.

Program Voice Terminals for Personal Priorities

These procedures are optional. Perform them at individual voice terminals whenever you want to give someone access to these features.

- Assign features to programmable buttons.
- Assign Personal Speed Dial codes to 5- and 10-button voice terminals.
- Use special characters in programmed dialing sequences.
- Select a Personalized Ring.
- Program Voice Announcement Disable.


MERLIN System Components

When performing your administrative tasks, you work with three components of the MERLIN system: the control unit, the administrator/attendant console, and individual voice terminals. The following descriptions provide information that helps you to become familiar with the equipment you use to administer your system. To make sure your equipment is properly installed, refer to the *Installation Guide: Models 1030 and 3070*.

You may also have some optional equipment that adds features and capabilities to your system, but does not affect system administration. For more information on optional equipment, see page 11.

THE MODEL 1030 CONTROL UNIT AND EXPANSION UNIT

The Model 1030 control unit provides connections for up to 20 outside lines and 20 voice terminals. The addition of an Expansion Unit makes the Model 1030 control unit a Model 3070 control unit and increases system capacity to up to 50 outside lines and 50 voice terminals.



Model 1030 Control Unit

1. **Power Module (slot 1):** Reduces ac power to a level the system can handle.
 - **Circuit Breakers.** Automatically cut the power to the control unit if an overload occurs.
 - **Ring Generator jack.** Connects optional Ring Generator Unit, which is required if you have basic Touch-Tone or rotary telephones connected to your system.
 - **Auxiliary Generator jacks.** Connect up to two Auxiliary Power Units to provide extra power for systems with many optional accessories.
 - **Power light (green).** Indicates power is on.
 - **On/Off switch.** Turns the power to the control unit on and off.
2. **Processor Module (slot 2):** Works with Feature Module 3. Switch settings on this module control system operating conditions.
 - **Switches A through H.** Select options provided by Feature Module 3.
 - **Warning light (red).** Warns of problem in control unit.
3. **Feature Module 3 (slot 3):** Enables your MERLIN system to work with your PBX/Centrex system.
 - **Attendant/Administer option.** Selects attendant or administration mode of operation for the administrator/attendant console (intercom number 10).
 - **Normal/Attendant options.** Select either normal (non-attendant) or attendant (receptionist or answering position) operation for seven voice terminals (intercom numbers 11 through 17).
4. **Diagnostics Module (slot 4, optional):** Aids you in identifying faulty components when the system malfunctions.
5. **Voice Terminal Module (slots 6 and 9):** Provides jacks for ten voice terminals. You

can have up to two Voice Terminal Modules in the Model 1030 control unit. You can have three additional modules in the Expansion Unit (Model 3070 only) for a total of five Voice Terminal Modules.

In the Model 1030 control unit, the Voice Terminal Module for intercom numbers 10 through 19 occupies slot 6. However, if you have the optional Services Module (Model 3070 only), this Voice Terminal Module (for intercom numbers 10 through 19) moves to slot 26 in the Expansion Unit and the Services Module occupies slot 6 (see page 8).

If you have basic Touch-Tone or rotary telephones in your system, you must use Basic Telephone Modules. Each Basic Telephone Module has jacks for up to five basic Touch-Tone or rotary telephones. Use a Basic Telephone Module in place of any Voice Terminal Module except the one for intercom numbers 10 through 19. Basic telephones connected to Basic Telephone Modules have access to one primary line and to all PBX/Centrex features (see "Special Information about Basic Telephones," page 48).


- 0 begins the numbering for the first five voice terminal jacks on the module. These jacks (and the location of the module) determine the intercom numbers of the voice terminals plugged into them. For example, if a Voice Terminal Module is plugged into the slot labeled Intercoms 20-29, the jack labeled 0 is for intercom 20. The jack below it is for intercom 21, and so on.
 - 5 begins the numbering for the second five voice terminal jacks.
6. **Line Module (slots 7, 8, 10, and 11):** Provides jacks for up to five PBX/Centrex lines. You may have up to four Line Modules in the Model 1030 control unit. In the Model 3070 control unit you can have six additional Line Modules for a total of ten Line Modules.

Model 3070 Control Unit

Addition of the Expansion Unit transforms the Model 1030 control unit into a Model 3070 control unit. The Expansion Unit increases overall system capacity from 20 lines and 20 voice terminals to 50 lines and 50 voice terminals. It can accommodate:

- Up to two Power Modules (slots 16 and 27).
- Up to six Line Modules (slots 17 through 20, 24, 25)
- Up to four Voice Terminal or Basic Telephone Modules (slots 21 through 23, 26)

NOTE: The Expansion Unit with one Power Module (slot 16) can support a maximum of three Voice Terminal Modules and two Line Modules. You need a second Power Module (slot 27) if your system exceeds this limit.



Services Module (optional): Connects optional equipment. The optional Services Module must occupy slot 6. The Voice Terminal Module for intercom numbers 10 through 19, which usually occupies slot 6, then moves to slot 26. The Services Module provides connections for music, paging, and power failure equipment as follows:

- **PFTT (Power Failure Transfer Telephone) jack.** Permits connection of four basic telephones for use as backup during commercial power outage. The system automatically switches the lines plugged into Line Module jacks A0 through A3 to these telephones if power fails.
- **Page jack.** Connects a loudspeaker paging system for up to three paging zones.
- **Music In jack.** Connects a music source for Music-on-Hold or background music through a paging system.
- **MOH Vol (Music-on-Hold Volume) control.** Allows volume adjustment for Music-on-Hold.
- **Bkgd Vol (Background Volume) control.** Allows volume adjustment for background music.
- **Page Sgnl switch.** Provides a short tone before loudspeaker paging announcements when set to *On*; eliminates the tone when set to *Off*.
- **Level switch.** Sets amplification of music source. *Hi* is for sources with their own amplifiers, *Lo* for those without.

THE ADMINISTRATOR/ATTENDANT CONSOLE

The administrator/attendant console is the voice terminal connected to the intercom 10 Voice Terminal Module jack in the control unit. The console operates in either of two ways:

- It functions as your primary attendant console under ordinary day-to-day conditions.
- It functions as your administrator console when it is used to perform many of the system administration procedures explained later in this document.

To change the administrator/attendant console from one mode of operation to the other, you simply set a switch on the control unit and then set another switch on the console itself. When the console is in administration mode, some of its buttons take on different functions than they do when the console is in the regular call-handling mode. Therefore, you insert a special set of administration mode button labels in the console so that you know which buttons to touch when you administer the system. Two sets of button labels, one for a small console and another for a large console, are in the back of this manual.

The type of administrator/attendant console you have depends on the size of your system. In systems with 30 or fewer voice terminals or 30 or fewer lines, the administrator/attendant console is a *34-button deluxe voice terminal*. Only a 34-button deluxe model is suitable for system administration, because it has lights next to each programmable button. You use the lights to keep track of what is happening on the lines and voice terminals you are working with. In systems with more than 30 lines or more than 30 voice terminals, the administrator/attendant console is a *34-button deluxe voice terminal with an attached Attendant Intercom Selector*. Only this type of console is suitable for system administration because some aspects of administration require the use of the Attendant Intercom Selector. Illustrations of small and large consoles with administration mode button labels are on pages 12 and 13.

Using the Console

When you administer your system, you frequently use the Auto Intercom buttons and Shift buttons (large consoles only) on the administrator/attendant console.

Auto Intercom Buttons. Each person's voice terminal has a unique 2-digit intercom number similar to an extension number. These numbers (10 through 39 for a system with 30 voice terminals, or 10 through 59 for a system with 50 voice terminals) are automatically assigned to Auto intercom buttons on the console. During system administration, you use the lights next to each Auto Intercom button to find out which call restrictions and other options are assigned to each voice terminal in your system.


Shift Buttons (large console only). The large console has three Shift buttons that enable you to administer as many as 50 voice terminals by using only the 30 Auto Intercom buttons on the Attendant Intercom Selector. When you touch one of the Shift buttons, you change the intercom numbers assigned to the Auto Intercom buttons. Use the left Shift button labeled 10-20-30 to select intercom numbers 10 through 39 in the blue band, the center Shift button labeled 40-50-60 to select intercom numbers 40 through 59 and 10 programmable buttons in the white band, and the right Shift button labeled 70-80-90 to select 30 additional programmable buttons. If you want to dial a particular intercom number, you must first touch the Shift button that provides access to the group of intercom numbers that includes the one you want. For example, if you want to assign lines to the voice terminal represented by intercom 31, touch the left Shift button. The light next to the Shift button comes on, and the Auto Intercom buttons now represent intercom numbers 10 through 39.

OPTIONAL EQUIPMENT

Although you need only the control unit and the administrator/attendant console to administer your system, you may also have optional equipment that adds features and capabilities to your system.

- **Attendant Intercom Selector.** Provides an attendant with 30 additional buttons.
- **Manual and Automatic Multipurpose Adapters.** Allows you to connect accessories, such as computer modems, to any MERLIN system voice terminal.
- **Basic Telephone Module.** Lets you connect basic Touch-Tone and rotary telephones to the MERLIN system.
- **Hands-Free Unit.** Provides you with full speakerphone capability including hands-free telephone conversation, On-Hook Dialing, Monitor-on-Hold, and teleconferencing. The unit requires a programmable button on the voice terminal if you want it to go on automatically when intercom calls ring at the voice terminal.
- **Headset and Headset Adapter.** Enable an attendant to answer and listen to calls without lifting the handset.


Small Administrator/Attendant Console in Administration Mode



1. **Conference, Drop**, and **Transfer** are preprogrammed to act like a switchhook flash unless you program dialing sequences on these buttons that access the PBX/Centrex features.
2. Set the T/P switch to *P* during administration mode.
3. Touch **Adm Tel** when administering individual voice terminals from the administrator/attendant console.
4. Touch **Adm Opt** when administering the whole system from the administrator/attendant console.
5. Line or Auto Intercom buttons.
6. Touch **Copy** to give a voice terminal the same line assignments and call restrictions as one that has already been set up.
7. Touch **Call Rstr** when assigning call restrictions to individual voice terminals.

Large Administrator/Attendant Console in Administration Mode

The large console provides the same features as the small console, but it has more line and Auto Intercom buttons. You need a large console if your system has more than 30 lines or 30 voice terminals.



1. Line buttons.
2. Line or Auto Intercom buttons, depending on the number of lines in your system.
3. Buttons in this column represent intercom numbers 10-19, 40-49, and lines G0-H4, depending on which Shift button you touch.
4. Buttons in this column represent intercom numbers 20-29 or 50-59 or lines I0-J4, depending on which Shift button you touch.
5. Buttons in this column represent intercom numbers 30-39, which you access by touching the leftmost Shift button.
6. Touch this Shift button to use Auto Intercom buttons for intercom numbers 10-39.
7. Touch this Shift button to use Auto Intercom buttons for intercom numbers 40-59.
8. Touch this Shift button to access lines G0-J4.

Preparing to Administer Your System

Before you start to administer your system, review this section to make sure you have the information and completed forms that you need.

Prepare for System Administration

These procedures help you get ready to administer your system.

- Fill out System Configuration Forms.
- Select a time to administer your system.
- Review how to enter and leave administration mode.

THE FORMS AND LABELS YOU NEED

Before you begin performing administration procedures, be sure to complete all the necessary forms:

- A System Configuration Form to keep a record of how the lines in your system are arranged.
- Voice Terminal Configuration Forms to record the lines and features assigned to all voice terminals. Fill out one of these for each voice terminal.

You should have filled out these forms when you completed the *MERLIN Communications System Planning Guide: Models 1030 and 3070*. If you did not, copy the ones in the Appendix and fill them out before you proceed further. These forms serve as important references throughout system administration procedures.

During system administration the buttons on the administrator/attendant console perform completely different functions than they do when the console is being used to handle calls. Therefore, you need a different set of button labels whenever you use the console for system administration. There are two sets of preprinted administration mode button labels in the back of this manual: one set for large consoles, and one set for small consoles. Keep the labels and completed forms to use whenever you administer your system.

CHOOSING A TIME TO ADMINISTER YOUR SYSTEM

Before you begin administration procedures, choose a time when you do not expect many people to be using their voice terminals. When you perform some administration procedures, the system blocks all calls on the lines or voice terminals with which you are working. Blocked voice terminals generate soft, periodic beeps to alert people that they cannot use them. If you accidentally try to administer a voice terminal that has an active call, you do not cut off the caller. Rather, you are unable to administer that voice terminal until it is idle.

ADMINISTRATION MODE

Administration mode is an operating state of your control unit and of your administrator/attendant console that is very different from their everyday state of operation. With the system in administration mode, you are able to set up or change system-wide options or features. When you put the system into administration mode, the buttons on the administrator/attendant console take on entirely different functions from those they perform when the console is in regular call-handling mode.

Entering and Leaving Administration Mode

You must enter administration mode whenever you use the administrator/attendant console to administer your system. The boxed instructions below tell you how to enter administration mode.

Entering Administration Mode

1. Set switch A on the Processor Module of the control unit to *Administer* (down).
2. Insert the administration mode button labels (see the back of this manual) in the administrator/attendant console.
3. Slide the T/P (Test/Program) switch on the left side of the console to *P*.
*Red and green lights start flashing next to the administration mode buttons labeled **Adm Opt** and **Adm Tel**.*

When you finish administration procedures at the console, you must leave administration mode to resume normal operation. Do this when you complete your initial system administration and whenever you complete any changes in the future. The boxed instructions below tell you how to leave administration mode.

Leaving Administration Mode

1. Slide the T/P switch to the center position.
2. Set switch A on the Processor Module of the control unit to *Attendant* (up).
3. Remove the administration mode button labels from the console and insert the regular call-handling labels used by the attendant.

Basic Administration

Once your system planning and paperwork are complete, you can perform basic administration procedures. The chart below summarizes the procedures described in this section. Remember that if you are administering a new system that has just been installed, some of these basic produce may be *required* to set the proper operating conditions for your particular environment, and you must perform them first before you go on to do any other system administration. Carry out the procedures in the order listed in the chart, but keep in mind that you may not need to perform all of them to customize your system to your particular environment. Read each procedure first to see if it applies to you.

IMPORTANT: Choose a time when you do not expect many people to be using their voice terminals.

Perform Basic Administration

- Set your control unit.
- Specify Touch-Tone or rotary dialing.
- Assign lines and call restrictions to voice terminals.
- Assign PBX/Centrex extensions to line buttons.
- Administer fixed feature buttons.

SETTING YOUR CONTROL UNIT

The first step in administering your MERLIN system is to set the control unit to conform to certain operating conditions of your system. Follow these steps to set your control unit:

1. Turn off the control unit by setting the On/Off switch on the Power Module to *Off*.
2. Set switch A on the Processor Module to *Administer* (down).

Set switch A to this position whenever you need to customize your system from the administrator/attendant console. When you finish customizing, set switch A to *Attendant* (up).

NOTE: Switch A is the only switch on the control unit that you can reset with the power on. If you reset any other switch with the power on, *the control unit does not record any of the changes you make.*

3. Set switches B through H on the Processor Module.

These switches control the voice terminals for intercom numbers 11 through 17, respectively. You can designate any of these seven voice terminals as attendant consoles. These seven voice terminals plus the administrator/attendant console (intercom 10) provide a maximum of eight attendant consoles, should you need them.

- For voice terminals that function as attendant consoles, set the corresponding switch to *Attendant* (down).
 - For voice terminals that function as regular telephones, set the corresponding switch to *Normal* (up).
4. Set the On/Off switch on the Power Module to *On*. This records the changes you just made.
 5. If you have the optional Service Module (Model 3070 only), which connects optional equipment, you can make any of the following adjustments:
 - If you have background music through a loudspeaker paging system, raise the volume by turning the Bkgd Vol control clockwise, or lower the volume by turning the control counterclockwise.
 - If you have Music-on-Hold, raise the volume by turning the MOH Vol control clockwise, or lower the volume by turning the control counterclockwise.
 - If you have a music source with its own amplifier, set the Level switch to *Hi* (down); otherwise, set it to *Lo* (up).
 - If you have a loudspeaker paging system connected to your MERLIN system and want a short tone to precede loudspeaker announcement set the Page Sgnl switch to *On* (up); if your paging system already provides a short tone or if you do not want one, set the switch to *Off* (down).

SPECIFYING TOUCH-TONE OR ROTARY DIALING

When your system is first installed, it is set for Touch-Tone dialing; so if some of your lines are rotary you need to reset the system for rotary dialing. To determine if your lines are Touch-Tone or rotary, go to the administrator/attendant console and make sure the T/P switch is in the center position. Then touch each line button and dial out. If a line is Touch-Tone, you hear tones and the dial tone stops. If a line is rotary, you hear tones but the dial tone is not interrupted. Follow the procedure below to specify Touch-Tone or rotary dialing.

1. If you have not already done so, enter administration mode by following the boxed instructions on page 16.

2. Touch **Adm Opt**.

*The green light beside **Adm Tel** goes out and the green light beside **Adm Opt** flashes slowly.*

3. Dial 3.

*The green light beside **Adm Opt** stops flashing and remains on.*

4. One by one, touch each line button until the green light beside it shows the appropriate code. Each successive touch gives you one of these codes:

*Steady green on = Touch-Tone signaling
Green off = rotary signaling*

5. Continue to administer your system, or if you have no further system administration to do, leave administration mode by following the boxed instructions on page 16.

ASSIGNING LINES AND CALL RESTRICTIONS TO VOICE TERMINALS

Each voice terminal in the MERLIN system has its own outside line for receiving incoming calls. This line is the voice terminal's primary line, although the voice terminal may also have access to additional lines. The system automatically assigns a voice terminal's primary line to the button above **Intercom-Voice**, and this is the line that the system selects when you lift your handset to place a call.

Assigning Primary Lines

You may need to change primary line assignments at the control unit to meet your business needs. Before you unplug any of the primary lines from their jacks, you must first determine where a voice terminal's primary line is plugged into the control unit. Each Line Module slot in the control unit is labeled with a letter. Each Line Module has jacks labeled 0 through 4. Both the module and the jack to which a line connects determine the line designation. For example, the Line Module in slot 7 is lettered A, so the jacks in that Line Module are called A0, A1, A2, A3, and A4, and correspond to intercom numbers 10, 11, 12, 13, and 14, respectively. For a complete list of the jack-to-intercom correspondence, see the System Configuration Form on pages 61-62.

Assigning Secondary Lines and Call Restrictions

If you want a voice terminal to have any lines in addition to the line, you must specifically assign them. These lines, called secondary lines, are automatically set to ring only after a delay. Several people may share the same secondary line, giving them access to more than one line and making it easy to answer someone else's calls, if necessary. You can assign up to 12 secondary lines to a single voice terminal, depending on how many buttons with lights are available. For example, you can assign a 5-button voice terminal a maximum of two secondary lines and a 10-button voice terminal a maximum of seven secondary lines.

When your system is first installed, all voice terminals can make intercom, PBX/Centrex extension, and outside calls; however, you can restrict them if necessary. You use your MERLIN system to restrict voice terminals to only intercom and PBX/Centrex extension calls. You use your PBX/Centrex system to assign any other calling restrictions.

If you are assigning secondary lines or call restrictions for the first time, please read the following information.

- Your voice terminal buttons may not have been labeled at the time your system was installed. You have to label the voice terminal buttons with any lines you assign, such as WATS lines, or any initial features.
- To assign lines, you need a completed Voice Terminal Configuration Form for each voice terminal you intend to administer (see the Appendix).
- When your system is first installed, attendant consoles have green lights next to as many line buttons as you have Line Module jacks. If, for example, your business only uses three of the five line jacks in a particular Line Module, the remaining two lines still appear on the attendant consoles, but have no dial tone. These unused lines have to be removed at the administrator/attendant console in administration mode before you can program the line buttons for other uses.
- If someone regularly covers calls that come in on another person's line (for example, a secretary who answers a manager's line), try to assign that line to both people. (If you cannot, use a Cover button, page 32.)
- 5-Button voice terminals are limited to three line buttons because of the two fixed Intercom buttons. If anyone using a 5-button voice terminal must access a special line such as a WATS line, be sure that it is assigned to one of the three line buttons.
- Initially, in systems with 30 lines or less, all attendant consoles display exactly the same lines. If you want certain lines to be answered on your primary attendant console, and certain lines to be answered on your secondary attendant console, you have to administer your consoles to appear this way. In systems with more than 30 lines, all attendant consoles display only the first 30 lines. You can change the line assignments on any attendant console so only the additional lines appear (see "Special Information about Attendant Consoles," page 43).

Now, follow the procedure below.

1. If you have not already done so, enter administration mode by following the boxed instructions on page 16.

2. Touch **Adm Tel**.

*The green light beside **Adm Opt** goes out and the green light beside **Adm Tel** stops flashing and remains on.*

3. Dial the intercom number of the voice terminal whose lines you want to assign.

A steady green light comes on next to the Auto Intercom button, and the console gives a 2-beep signal for you to begin.

If the green lights beside both the Auto Intercom button and **Adm Tel** flash rapidly instead, the voice terminal is in use. Wait until the green lights become steady, or you can try again later.

4. Refer to the Voice Terminal Configuration Form to see which lines you plan to have this voice terminal use.

5. If a green light is on next to a line button, the voice terminal can use that line. Touch any line button that is showing a green light and that you do not want assigned to this voice terminal.

The green light goes off, confirming that the line no longer appears at the voice terminal.

6. Touch any line button that is not showing a green light and that you want assigned to this voice terminal.

The green light comes on, confirming that the line now appears at the voice terminal.

7. If you do not want to restrict voice terminals, go to step 8. Otherwise, touch the button labeled **Call Rstr** until the green light beside it shows the code associated with the calling restrictions you want this voice terminal to have. Each successive touch gives you one of these codes:

Steady green on = all calls permitted

*Flashing green = PBX/Centrex extensions and
MERLIN intercom calls only*

Green off = MERLIN intercom calls only

8. Repeat steps 3 through 7 until you have assigned lines and call restrictions to all the voice terminals. If you want to give other voice terminals the same secondary lines and call restrictions as one that has already been set up, use this shortcut for each voice terminal:

- Dial the intercom number of the voice terminal that you want to have the same lines and call restrictions as another voice terminal.
- Touch **Copy**.
- Dial the intercom number of the voice terminal whose lines and call restrictions you want to copy.

9. Continue to administer your system, or, if you have no further system administration to do, leave administration mode by following the boxed instructions on page 16.

ASSIGNING PBX/CENTREX EXTENSIONS TO LINE BUTTONS (Attendant consoles only)

Line buttons on attendant consoles do double duty. They can be used for placing or receiving calls, and they can be used like Auto Intercom buttons for quick dialing of and one-touch transfer to extensions. Before an attendant can use the line buttons for quick dialing and transferring you must assign PBX/Centrex extensions to the line buttons on the console. To assign a PBX/Centrex extension to a line button, follow the procedure below.

1. If you have not already done so, enter administration mode by following the boxed instructions on page 16.
2. Label the button with the extension number you are assigning to it.
3. Touch **Adm Opt**.
*The green light beside **Adm Tel** goes out, and the green light beside **Adm Opt** flashes slowly.*
4. Dial 1.
*The green light beside **Adm Opt** stops flashing and remains on.*
5. Touch the line button.
The green light next to the button comes on.
6. Dial the PBX/Centrex extension number, six digits or less, that corresponds to the line selected.
7. Repeat steps 5 and 6 until you have assigned extensions to all your line buttons.
8. Continue to administer your system, or, if you have no further system administration to do, leave administration mode by following the boxed instructions on page 16.

ADMINISTERING FIXED FEATURE BUTTONS

When your system is first installed, the buttons labeled **Transfer**, **Drop**, and **Conference** on all voice terminals are automatically programmed to act like a switchhook flash (a brief press of the switchhook). Most PBX/Centrex systems use a switchhook flash to access these features; however, some systems may use a dial code instead. Refer to the user's guide for your PBX/Centrex system to find out what your system requirements are. If your system uses a switchhook flash, you do not need to perform this procedure. If your system uses dial codes, follow the procedure below to assign dial codes to these buttons.

1. If you have not already done so, enter administration mode by following the boxed instructions on page 16.

2. Touch **Adm Opt**.

*The green light beside **Adm Tel** goes out, and the green light beside **Adm Opt** flashes slowly.*

3. Dial 2.

*The green light beside **Adm Opt** stops flashing and remains on.*

4. Touch the fixed feature button you intend to administer (for example, **Transfer**).

5. Enter up to six characters for the dial code sequence, for example 0 through 9, #, *, a switchhook flash (touch **Recall** and then **Hold**), or a pause (touch **Hold**). For more information about these characters, see "Using Special Characters in Programmed Dialing Sequences," page 39.

6. Repeat steps 4 and 5 for the remaining fixed feature buttons.

7. Continue to administer your system, or, if you have no further system administration to do, leave administration mode by following the boxed instructions on page 16.

Customizing with Additional System Options

Once basic administration is complete, you may perform other optional administration procedures any time you want to add systemwide features. The chart below summarizes the procedures described in this section.

Customize with Additional System Options

- Assign Call Coverage permissions.
- Assign Call Pickup permissions.
- Block the system from incoming calls.

ASSIGNING CALL COVERAGE PERMISSIONS

Using the Call Coverage feature, a person can program his or her voice terminal to receive calls directed to another voice terminal and thus cover a co-worker's calls. However, you must first assign Call Coverage permission to the voice terminal being covered. When your system is first installed, it is set so that no voice terminals can be covered. To assign Call Coverage permissions, follow the procedure below.

1. If you have not already done so, enter administration mode by following the boxed instructions on page 16.
2. Touch **Adm Opt**.
*The green light beside **Adm Tel** goes out, and the green light beside **Adm Opt** flashes slowly.*
3. Dial 5.
*The green light beside **Adm Opt** stops flashing and remains on.*
4. Dial the intercom number for the voice terminal whose calls you want covered.
The green lights come on next to the primary line buttons of the voice terminals that can cover this voice terminal's calls.
5. One by one, touch each line button until the green light beside it shows the appropriate code. Each successive touch gives you one of these codes:
Steady green on = the voice terminal associated with this primary line can cover calls for this intercom number
Green off = the voice terminal associated with this primary line cannot cover calls for this intercom number
6. Repeat steps 4 and 5 until you have assigned all Call Coverage permissions.
7. Continue to administer your system, or, if you have no further system administration to do, leave administration mode by following the boxed instructions on page 16.

ASSIGNING CALL PICKUP PERMISSIONS

The Call Pickup feature allows people to answer calls ringing at other voice terminals. It is especially useful for voice terminals that do not require the full coverage provided by the Call Coverage feature. For example, John hears Patricia's phone ringing in her office next door. After several rings, he realizes she is away from her desk. John may answer her call from his voice terminal and take a message if you have assigned permission for Patricia's calls to be answered. Your system is initially set so no one's calls can be picked up. To assign Call Pickup permissions, follow the procedure below.

1. If you have not already done so, enter administration mode by following the boxed instructions on page 16.
2. Touch **Adm Opt**.
*The green light beside **Adm Tel** goes out, and the green light beside **Adm Opt** flashes slowly.*
3. Dial 4.
*The green light beside **Adm Opt** stops flashing and remains on.*
The green lights come on next to the primary line buttons of the voice terminals whose calls can be picked up.
4. One by one, touch each primary line button until the green light beside it shows the appropriate code. Each successive touch gives you one of these codes:
Steady green on = the voice terminal's calls can be picked up
Green off = the voice terminal's calls cannot be picked up
5. Continue to administer your system, or, if you have no further system administration to do, leave administration mode by following the boxed instructions on page 16.

BLOCKING THE SYSTEM FROM INCOMING CALLS

Before you can make certain hardware changes at the control unit, such as adding or replacing a Line or Voice Terminal Module, you must first turn off the system. If you do this while people are making calls, their calls are dropped. So, before making these changes at the control unit, you must first be sure no one is using a voice terminal, and then block all incoming calls to the system by following the procedure below.

1. If you have not already done so, enter administration mode by following the boxed instructions on page 16.

2. Touch **Adm Opt**.

*The green light beside **Adm Tel** goes out, and the green light beside **Adm Opt** flashes slowly.*

3. Dial 0.

*The green light next to **Adm Opt** remains on.*

If the green light next to **Adm Opt** continues to flash, your system is in use. When this happens, the system continues to check the lines and voice terminals; when all lines are free, the green light becomes steady and you hear a 2-beep signal. If you do not want to wait, you can leave administration mode by following the boxed instructions on page 16 and try again later.

4. Once you get the 2-beep signal and steady green light, all incoming calls are blocked, and you can now turn the power off at the control unit in order to make any changes.
5. After you have finished making changes, turn the power on. The system can now receive incoming calls.
6. Continue to administer your system, or, if you have no further system administration to do, leave administration mode by following the boxed instructions on page 16.


Programming Voice Terminals for Office Priorities

The people in your business can customize their voice terminals by changing initial custom feature assignments to suit their needs. Most of the features are designed primarily for the convenience of the person using them, but some have a broader application because they affect the calling patterns of your business. These features include Programmable Line Ringing, Call Coverage, and Automatic Line Selection. Because these features have a businesswide influence, you may want to oversee their assignment. The chart below summarizes the procedures presented in this section.

Program Voice Terminals for Office Priorities

- Assign an Automatic Line Selection sequence.
- Assign Programmable Line Ringing for incoming calls.
- Assign Cover buttons.

Initial Feature Assignments for All Non-attendant Voice Terminals



ASSIGNING AN AUTOMATIC LINE SELECTION SEQUENCE

Automatic Line Selection is a MERLIN system feature that gives you a free line whenever you lift the handset. When your system is first installed, it is set to select your primary line first. If you always use your primary line to make calls, there is no need to reprogram the Automatic Line Selection sequence. However, if you use secondary or intercom lines more frequently, you may want to reprogram the order in which the system selects the lines for each voice terminal. Before you assign an Automatic Line Selection sequence, please read the following information.

- If you are programming several features during one session, perform this procedure first, immediately after you enter program mode. You may include a maximum of eight lines in the Automatic Line Selection sequence.
- If the lines on a voice terminal are all interchangeable with one another (for example, all regular PBX/Centrex lines), you may prefer not to program this feature at all.
- Program only similar types of lines in the Automatic Line Selection sequence, that is, all PBX/Centrex lines or all Foreign Exchange (FX) lines to the same location.
- Never place both intercom and outside lines in an Automatic Line Selection sequence.
- To make your system cost-effective, program the lines in the selection sequence so the most frequently used line appears first. For example, if the person using the voice terminal frequently makes long distance calls, program a WATS line to be the first line in the sequence (make sure that all the lines in the programmed sequence are compatible). Also, placing a line first ensures that most outgoing calls are billed to that line. Placing a line last means that the line will usually be free for incoming calls.

Now, follow the procedure below.

1. Go to the voice terminal you want to program.
2. Slide the T/P switch on the left side of the voice terminal to *P*.
The voice terminal rings every 5 seconds to remind you it is in program mode.
3. Dial ** .
4. Touch the line buttons in the order you want the system to select them.
5. Dial ** .
6. If you have more features to program on this voice terminal, you can do so. Otherwise, slide the T/P switch to the center position to return to normal operation.

ASSIGNING PROGRAMMABLE LINE RINGING FOR INCOMING CALLS

You can program the line and Cover buttons on voice terminals to ring in one of three different ways for incoming calls: immediate ring, delayed ring, and no ring. When your system is first installed, all primary lines automatically ring immediately and all secondary lines ring after a delay. If you are assigning line ringing for the first time, please read the following information.

- **Immediate ring.** Assign immediate ringing of a line to anyone responsible for answering that line first (for example, an attendant, a secretary, or a receptionist). This option is also useful for lines that should not be screened or for people who answer their own calls.
- **Delayed ring.** Delayed ringing provides backup coverage on shared lines. When you assign delayed ringing to a line, the voice terminal does not ring until a call on that line rings twice at the covered voice terminal.

Assign delayed ringing to:

- Anyone responsible for answering a shared line only if someone else doesn't pick it up
 - A secretary on a manager's private line
 - A second secretary responsible for answering a shared line only if the primary secretary doesn't answer
 - Someone who acts as a backup for a primary attendant
- **No ring.** Assign "no ring" to lines on a voice terminal that are always answered first at another voice terminal, such as a business line that rings first at a secretary's voice terminal. This option is also appropriate for voice terminals in public places such as lobbies or conference rooms.
 - You may also want to program voice terminals, particularly attendant consoles, with a Ring Option Override button. This feature overrides any prior line ringing programming so that all incoming calls are answered right away. For programming procedures see "Assigning Features to Programmable Buttons," page 35.

Now, follow the procedure below.

1. Go to the voice terminal you want to program.
2. Slide the T/P switch on the left side of the voice terminal to *P*.

The voice terminal rings every 5 seconds to remind you it is in program mode.

3. Touch the line or Cover button you want to program until the red light beside it shows the appropriate code. Each successive touch gives you one of these codes:


Steady red on = immediate ring
Flashing red = delayed ring
Red off = no ring

4. Repeat steps 2 and 3 for each line you want to program.
5. If you have more features to program on this voice terminal, do so. Otherwise, slide the T/P switch to the center position to return to normal operation.

ASSIGNING COVER BUTTONS

When you assign a Cover button to a voice terminal, all calls for the covered voice terminal come in at the covering voice terminal. A Cover button is initially programmed not to ring; however you can program the line for immediate ring or delayed ring. The lights next to a Cover button work like the lights next to any line button, so you can tell when a call is coming in. You cannot use a Cover button to make a call. Before you can program a Cover button, be sure the voice terminal has permission to cover other voice terminals by following the procedures in "Assigning Call Coverage Permissions," page 25. If you are assigning Cover buttons for the first time, please read the following information.

- A Cover button may be programmed for primary or secondary coverage. Secondary coverage provides a second backup. Suppose, for example, that you assign Jim primary coverage with immediate ring for Susan's voice terminal (see the diagram below). Then each time a call rings at Susan's voice terminal it rings at the same time at Jim's voice terminal. To make certain that Susan's calls are answered when both Susan and Jim are away from their desks, you assign secondary coverage with delayed ring for Susan's voice terminal to Richard. This means that when a call comes in for Susan, it rings three times simultaneously at Susan's voice terminal and at Jim's voice terminal and then starts ringing at Richard's voice terminal. Jim's calls won't ring at Richard's voice terminal, however, unless you assign primary coverage for Jim's calls to Richard. With this system, up to five people can have Cover buttons for a single voice terminal.



PRIMARY AND SECONDARY COVERAGE

- Assign *primary coverage* to someone who must screen someone else's calls, but does not share all lines with that person. A secretary who answers a manager's calls, for example, would be assigned primary coverage of the manager's voice terminal. You may program a primary Cover button for either immediate or delayed ringing, depending upon the situation and personal preferences.

- Assign *secondary coverage* to anyone who is a backup for the covering voice terminal, such as a clerk who covers calls for a group secretary. A voice terminal programmed with a secondary Cover button does not ring until a call rings twice at a voice terminal assigned primary coverage.
- If all calls in your business come in through the attendant's console, you can assign a Cover button to another voice terminal and program it not to ring. This is useful for people who sometimes work when the attendant is not on duty. They can tell by the flashing green light that someone is calling and can answer the call if they want to, but they do not have to be bothered by ringing after regular business hours.
- Be sure to choose a programmable button with lights, and program no more than five Cover buttons on any one voice terminal.
- The attendant needs a Cover button for any voice terminal with a line not assigned to that attendant console but that must be covered if no one answers. A Cover button is also necessary if the attendant must cover intercom calls for someone.

Now, follow the procedure below.

1. Go to the voice terminal you want to program.
2. Label the Cover button with the name of the person whose calls the button covers.
3. Slide the T/P switch on the left side of the voice terminal to *P*.
The voice terminal rings every 5 seconds to remind you it is in program mode.
4. Touch the Cover button.
5. Dial * 4 to program primary coverage, or dial * 5 to program secondary coverage.
6. Dial the 2-digit intercom number of the voice terminal the button covers.
7. If you want to program line ringing options for the Cover button, touch the button repeatedly until the red light beside it shows the appropriate code. Each successive touch gives you one of these codes:
 - Steady red on = immediate ring*
 - Flashing red = delayed ring*
 - Red off = no ring*
8. If the green light comes on next to the Cover button, you have not performed the procedure correctly. Repeat steps 3 through 7.
9. If you have more features to program on this voice terminal, you can do so. Otherwise, slide the T/P switch to the center position to return to normal operation.

Programming Voice Terminals for Personal Priorities

By programming their own voice terminals, people can change the features on all but the fixed feature buttons and the line and Intercom buttons. This allows almost everyone to have features that provide personal convenience, such as an Outside Auto Dial button for calling home. The chart below summarizes the procedures described in this section.

Program Voice Terminals for Personal Priorities

- Assign features to programmable buttons.
- Assign Personal Speed Dial codes to 5- and 10-button voice terminals.
- Use special characters in programmed dialing sequences.
- Select a Personalized Ring.
- Program Voice Announcement Disable.

ASSIGNING FEATURES TO PROGRAMMABLE BUTTONS










As system administrator you may have to decide which custom features certain voice terminals should have, taking into consideration the individual's needs and the capabilities of the voice terminal. The Feature Programming Chart, pages 36 and 37, lists the programming codes you use to assign the features, and the initial feature assignments diagrams, pages 29, 44, and 45, show what features are automatically assigned to the voice terminals. Before assigning features, please read the following information.

- Some features require buttons with lights to indicate whether the feature is activated. These features are Do Not Disturb, Privacy, Auto Answer-Intercom, Auto Answer-Outside, Shift and Ring Option Override.
- A button with lights is recommended but not required for the Auto Intercom and Loudspeaker Page features.











Now, follow the procedure below.

1. Go to the voice terminal you want to program.
2. Label the button(s) with the name of feature(s) you want to program.
3. Slide the T/P switch on the left side of the voice terminal to *P*.
The voice terminal rings every 5 seconds to remind you it is in program mode.
4. Touch the button that you have labeled.
5. Dial the appropriate feature programming code and any additional numbers or characters, if required, from the Feature Programming Chart, pages 36 and 37. If you make a mistake, touch the button again and redial the information.
6. If you have more features to assign, you can do so by repeating steps 4 and 5. Otherwise, slide the T/P switch to the center position to return to normal operation.

Feature Programming Chart

Feature Name (Suggested Button Label)	Description	Programming Code	Notes
Outside Auto Dial 	Dial outside telephone numbers, PBX/Centrex extensions, PBX/Centrex feature codes with one touch.	<ul style="list-style-type: none"> • Dial * 90. • Dial an outside access code and pause, followed by an outside number, or dial a PBX/Centrex extension number or a PBX/Centrex feature code. 	
Auto Intercom 	Simplify dialing MERLIN system intercom numbers.	<ul style="list-style-type: none"> • Dial * 91. • Dial a 2-digit MERLIN system intercom number. 	A button with lights is recommended but not required.
Speed Dial Access 	Use with Personal Speed Dial, Saved Number Redial, and Last Number Redial.	<ul style="list-style-type: none"> • Dial * 94. 	For 5- or 10-button voice terminals only.
Personal Speed Dial (does not use a button)	Assign a 2-character code (01 through 22) to each telephone number you call frequently.	<ul style="list-style-type: none"> • Touch Speed Dial Access. • Dial a Personal Speed Dial code (01 through 22). • Dial * 90. • Dial an outside telephone number, a PBX/Centrex extension number or a PBX/Centrex feature code. 	For 5- or 10-button voice terminals only.
Last Number Redial 	Redial the number you dialed most recently.	<ul style="list-style-type: none"> • Dial * 73. (You do not need to dial an outside number.) 	If you have a 5- or 10-button voice terminal, you can dial a code to use this feature if you prefer not to use a button.
Saved Number Redial 	Save a number for later redialing.	<ul style="list-style-type: none"> • Dial * 74. (You do not need to dial an outside number.) 	If you have a 5- or 10-button voice terminal, you can dial a code to use this feature if you prefer not to use a button.
Intercom Conference 	Use conference participants' intercom number, thus not tying up your PBX/Centrex lines during conference calls.	<ul style="list-style-type: none"> • Dial * 96. 	
Intercom Drop 	Disconnect participants from the Intercom Conference call.	<ul style="list-style-type: none"> • Dial * 97. 	
Auto Answer-Outside 	Have a modem or answering machine go on automatically whenever an outside or PBX/Centrex call rings at your voice terminal.	<ul style="list-style-type: none"> • Dial * 75. 	Used only with a modem or answering machine. Requires a button with lights and a Multipurpose Adapter.
Auto Answer-Intercom 	Have an optional Hands-Free Unit go on automatically when you receive intercom calls.	<ul style="list-style-type: none"> • Dial * 70. 	Used only with a Hands-Free Unit. Requires a button with lights.

Feature Programming Chart (continued)

Feature Name (Suggested Button Label)	Description	Programming Code	Notes
Manual Signaling 	Generate a beep at another person's voice terminal.	<ul style="list-style-type: none"> Dial * 6. Dial the intercom number for the person you want to contact. 	Use Manual Signaling to contact someone with a prearranged signal. If you program this feature on a button with lights, the green light goes on when the other person is using his or her voice terminal.
Privacy 	Prevent people from accidentally joining your calls.	<ul style="list-style-type: none"> Dial * 72. 	Needed only if you share lines with other people. Requires a button with lights.
Do Not Disturb 	Temporarily prevent calls from ringing at your voice terminal.	<ul style="list-style-type: none"> Dial * 71. 	Requires a button with lights.
Programmable Shift 	Use this button to program two features onto each button to the right of the dial pad.	<ul style="list-style-type: none"> Dial * 79. 	For 34-button voice terminals only. Must be programmed on one of the buttons above the dial pad.
Loudspeaker Page 	Use your business' loudspeaker paging system to make announcements to all or some of your co-workers.	<ul style="list-style-type: none"> Dial * 91 + a paging code: 80 for all zones 81 zone 1 82 zone 2 83 zone 3 	Used only with loudspeaker paging equipment.
Touch-Tone Enable 	If your system has lines that carry rotary pulse signals, you can switch to Touch-Tone signals to use services such as alternate long distance or credit card authorizations.	<ul style="list-style-type: none"> Dial * 76. 	For rotary lines only.
Call Coverage 	Receive calls for someone who is unable to answer his or her voice terminal.	<ul style="list-style-type: none"> Dial * 4. Dial the intercom number of the person you want to cover. 	Requires a button with lights. You can program up to five Cover buttons.
Secondary Coverage 	Receive calls, after a delay, as a backup for a co-worker who covers someone else's calls.	<ul style="list-style-type: none"> Dial * 5. Dial the intercom number of the person you want to cover. 	Requires a button with lights. You can program up to five Cover buttons.
Ring Option Override 	Use this button when you want all calls to ring immediately at your voice terminal, even if it is programmed to ring after a delay or not at all.	<ul style="list-style-type: none"> Dial * 78. 	Requires a button with lights.
Message 	Have your MERLIN system attendant notify you when you have a message.	<ul style="list-style-type: none"> Dial * 98. 	For 5-button voice terminals only. Requires a button with lights.

ASSIGNING PERSONAL SPEED DIAL CODES TO 5- AND 10-BUTTON VOICE TERMINALS

On 5- and 10-button voice terminals, you can program up to 22 Personal Speed Dial codes instead of Outside Auto Dial buttons for frequently used numbers. Before you can program Personal Speed Dial codes, however, you must program a Speed Dial Access button. To program Personal Speed Dial codes and a Speed Dial Access button, follow the procedure below.

1. Go to the voice terminal you want to program.
2. Slide the T/P switch on the left side of the voice terminal to *P*.
The voice terminal rings every 5 seconds to remind you it is in program mode.
3. If you already have a Speed Dial Access button, go to step 4. Otherwise, follow this procedure to program the Speed Dial Access button:
 - a. Label the button **Speed Dial Access**.
 - b. Touch the button.
 - c. Dial * 94.
4. Touch **Speed Dial Access**.
5. Dial the code you want to assign to the telephone number (available codes are 01 through 22).
6. Dial * 90.
7. Dial the telephone number (16-digit maximum).
If you need them, you may use the special character codes described in the section "Using Special Characters in Programmed Dialing Sequences," page 39.
8. If you have more telephone numbers to assign to Personal Speed Dial codes, you can do so by repeating steps 5-7. Otherwise, slide the T/P switch to the center position to return to normal operation.
9. Make a list of all Personal Speed Dial codes and the telephone numbers they represent.

USING SPECIAL CHARACTERS IN PROGRAMMED DIALING SEQUENCES

Special characters (pause, stop, and switchhook flash) are useful in programming PBX/Centrex features onto programmable feature buttons, or in programming special telephone numbers onto Outside Auto Dial buttons. These characters are counted as part of the 16-digit maximum you can store on Outside Auto Dial buttons and Personal Speed Dial codes. If you are programming special characters for the first time, please read the following information.

- If your PBX/Centrex system requires dialing a 9 or another outside access code to get an outside line, program a pause after the 9 on your Outside Auto Dial button. (You may need two or three pauses depending on how quickly your PBX/Centrex system returns a dial tone following the 9.)
- You may need to program an automatic stop when you dial an alternate long distance service sequence or dial a credit card authorization code.
- When using an Auto Dial button or a Personal Speed Dial code with a stop, resume the dialing sequence by touching the Auto Dial button or dialing the Personal Speed Dial code again after reaching the stop.
- Whenever your PBX/Centrex procedure calls for a switchhook flash, touch **Recall** instead. Program PBX/Centrex features that call for a switchhook flash onto a button or special Personal Speed Dial code for one-touch convenience.

Now, use the sample procedures below as guidelines to program special characters into a dialing sequence.

1. Go to the voice terminal you want to program.
2. Label the button with the special service names or outside location names and numbers.
3. Slide the T/P switch on the left side of the voice terminal to *P*.
The voice terminal rings every 5 seconds to remind you it is in program mode.
4. Touch the button you labeled for Outside Auto Dial or touch **Speed Dial Access** and dial a Personal Speed Dial code.
5. Dial * 90.
6. Touch **Hold** (Pause) to program a pause (1.5 seconds) into a dialing sequence. For example, to program a pause between an access code and a telephone number:
 - a. Dial 9 (or another outside line access code).
 - b. Touch **Hold** (Pause).
 - c. Dial the outside number you want the button to represent.
7. Touch **Drop** (Stop) to program a stop into a dialing sequence. For example, to program a stop between an alternate long distance telephone number and its access code:
 - a. Dial the alternate long distance telephone number.
 - b. Touch **Drop** (Stop).
 - c. Dial the authorization or access code (five or six digits).
8. Touch **Recall** and then **Hold** (Pause) to program a switchhook flash into a dialing sequence. For example, to program a switchhook flash for a Custom Calling or PBX/Centrex code:
 - a. Touch **Recall**.
 - b. Touch **Hold** (Pause).
 - c. Dial the PBX/Centrex dial code sequence that accesses the feature you want to program.
9. If you have more features to program on this voice terminal, you can do so. Otherwise, slide the T/P switch to the center position to return to normal operation.

SELECTING A PERSONALIZED RING

The MERLIN system offers a choice of eight different ringing sounds for any voice terminal. This enables people who sit in the same room to distinguish the ringing of their voice terminals from that of others. The personalized part of the ring occurs at the end of the ringing pattern, so it does not interfere with the distinctive ringing patterns that signal whether a call is PBX/Centrex, intercom, or from the outside. Follow the procedure below to program a Personalized Ring.

1. Go to the voice terminal you want to program.
2. Slide the T/P switch on the left side of the voice terminal to *P*.
The voice terminal rings every 5 seconds to remind you it is in program mode.
3. Touch **Speaker** repeatedly until you hear the ring you want.
4. If you have more features to assign, you can do so. Otherwise, slide the T/P switch to the center position to return to normal operation.

PROGRAMMING VOICE ANNOUNCEMENT DISABLE

When your system is installed, all voice terminals can receive both announced and ringing intercom calls. For some voice terminals, such as those in public locations, announcements are impractical. The Voice Announcement Disable feature suppresses voice announcements for intercom calls. Announced intercom calls to voice terminals programmed with this feature become ringing intercom calls. Follow the procedure below to program Voice Announcement Disable.

1. Go to the voice terminal you want to program.
2. Slide the T/P switch on the left side of the voice terminal to *P*.
The voice terminal rings every 5 seconds to remind you it is in program mode.
3. Touch **Intercom-Voice** until the green light next to it shows the appropriate code. Each successive touch activates one of these codes:
Steady green on = voice announcements permitted
Green off = voice announcements blocked
4. If you have more features to program on this voice terminal, you can do so. Otherwise, slide the T/P switch to the center position to return to normal operation.

Special Information about Attendant Consoles

All attendant consoles can support up to 30 lines, no matter what size system you have. If your system has more than 30 lines, only the first 30 lines are automatically assigned to all attendant consoles (see the initial feature assignment diagrams, pages 44 and 45), and you can readminister any attendant console with the additional lines. If you have 30 lines or less and want only certain lines to appear on certain attendant consoles, you can add or remove lines as best suits your business needs.

The *Attendant's Guide: Models 1030 and 3070 with Feature Module 3* describes the initial features that are preprogrammed on the attendant consoles, as well as other important features, and describes how to use them. Your attendant consoles serve you best, though, when they are customized to handle the calling patterns of your business. For example, an attendant should have an Auto Intercom button for every voice terminal that frequently receives calls.


If you have many lines, you need the large console, that is, a 34-button deluxe voice terminal with an Attendant Intercom Selector. The selector provides an additional 30 buttons that you can program with up to three features each. To access these features you touch Shift buttons. When you touch the Shift button labeled 10-20-30, you can access 30 Auto Intercom buttons (for intercoms 10 through 39), any or all of which you can reprogram with features. When you touch the Shift button labeled 40-50-60, you can access 20 Auto Intercom buttons (for intercoms 40 through 59) and 10 initially blank buttons. All 30 buttons can be reprogrammed with features. When you touch the Shift button labeled 70-80-90, you can access 30 initially blank buttons, any or all of which can be programmed with features. You may not be responsible for programming these buttons, but you may want to oversee the attendants when they program them. The selector also allows attendants to tell at a glance who has a Message light on. For more information regarding the Attendant Intercom Selector, refer to the *Attendant's Guide: Models 1030 and 3070 with Feature Module 3*.

ATTENDANT CONSOLE PROGRAMMING TIPS

- Procedures for line administration and feature programming are the same for the attendant consoles as for the other voice terminals in your system. To allow attendants to use line buttons for quick dialing of and one-touch transfer to extensions, you must assign PBX/Centrex extensions to line buttons (see page 22). The primary attendant console is always plugged into intercom 10. Intercoms 11 through 17 can be either attendant consoles or regular voice terminals.
- You probably want attendant lines to ring immediately when a call comes in, but there may be exceptions. For example, some people may want their lines to ring at the attendant console only if they are not available to answer.
- If you have more than one attendant, you can assign delayed ring to lines on one attendant console as a backup for the other and vice versa.
- If an attendant is not responsible for answering some lines on the attendant console, you can program those lines not to ring.
- The attendant needs a Cover button for any voice terminal with a line not assigned to that attendant console but that must be covered if no one answers. A Cover button is also necessary if the attendant must cover intercom calls for someone.
- If your PBX/Centrex has a loudspeaker paging system already connected to it, you can set it up so the attendant can page three separate zones independently. For example, a paging system in a medical group shared by several doctors could be set up with one zone covering only those locations specific to a particular doctor, such as a consulting office, lab, and examining room, and with two other zones covering other specific areas. Then, when a call comes in, the attendant can place the call on hold and page the appropriate zone without bothering anyone else.


Initial Feature Assignments for Attendant Consoles

34-Button Deluxe Voice Terminal



Initial Feature Assignments for Attendant Consoles with an Attendant Intercom Selector

34-Button Deluxe Voice Terminal with an Attendant Intercom Selector



Special Information about 34-Button Voice Terminals

There is only one difference between a standard 34-button voice terminal and a 34-button deluxe voice terminal. On the 34-button deluxe voice terminal, the 24 programmable buttons on the right have lights next to them; on the regular 34-button voice terminal, they do not.

A Last Number Redial button, a Saved Number Redial button, and at least 22 Outside Auto Dial buttons are a few of the features immediately available on a regular or deluxe 34-button voice terminal (see the initial feature assignments diagram, page 29). Other features, such as Privacy and Do Not Disturb, may also be assigned depending on how many buttons you have available.

34-BUTTON VOICE TERMINAL PROGRAMMING TIPS

- Program a Shift button if someone needs more than 24 programmable feature buttons. This button must be programmed on a button above the dial pad. With a Shift button you can program two features onto each button to the right of the dial pad.
- If someone has a Hands-Free Unit, program Auto Answer-Intercom onto a button with lights.
- If someone needs Privacy or Do Not Disturb, program the feature onto a button with lights.
- Have the person decide which intercom numbers he or she frequently calls and program an Auto Intercom button for each.
- If someone uses the loudspeaker paging system frequently, program a Loudspeaker Page button for each zone the person pages.
- Use all remaining buttons for Outside Auto Dial, and store frequently called numbers on them.

Special Information about 10-Button Voice Terminals

People with 10-button voice terminals have ten buttons above the dial pad for both lines and features. Depending on how many lines you have in your system, and how you have administered them to a particular 10-button voice terminal, you have up to seven available programmable buttons. See the programming tips for 34-button voice terminals, page 46, for more information about programming 10-button voice terminals.

10-BUTTON VOICE TERMINAL PROGRAMMING TIPS

- For frequently used telephone numbers, people using 10-button voice terminals can program up to 22 Personal Speed Dial codes and a Speed Dial Access button. These codes can be used in place of Outside Auto Dial buttons to access 22 different telephone numbers.
- People using 10-button voice terminals can access the Last Number Redial feature by touching the Speed Dial Access button and dialing 24 or by programming the Last Number Redial feature onto a button, if available. Similarly, they can access the Saved Number Redial feature by touching the Speed Dial Access button and dialing 23 or by programming the Saved Number Redial feature onto a button (see the initial feature assignments diagram, page 29).

Special Information about 5-Button Voice Terminals

If some people in your office have 5-button voice terminals, you may need to answer some questions for them or give them some special help.

5-BUTTON VOICE TERMINAL PROGRAMMING TIPS

- Buttons not assigned to intercom or outside lines are programmable.
- For frequently used telephone numbers, people using 5-button voice terminals can program up to 22 Personal Speed Dial codes and a Speed Dial Access button. These codes can then be used to access 22 different telephone numbers.
- People using 5-button voice terminals can access the Last Number Redial feature by touching the Speed Dial Access button and dialing 24. Similarly, people using 5-button voice terminals can access the Saved Number Redial feature by touching the Speed Dial Access button and dialing 23 (see the initial feature assignments diagram, page 29).

Special Information about Basic Telephones

If you have basic Touch-Tone or rotary telephones connected to a Basic Telephone Module, the people assigned these telephones only have access to one primary line because you cannot administer secondary lines to them. The people who use basic Touch-Tone or rotary telephones can access any PBX/Centrex features they are used to by using the procedures found in their PBX/Centrex system user's guide.

MERLIN System Features

The charts on the next few pages describe all the features of your system. The features are grouped alphabetically within three categories:

- **Fixed Features** are features that require no programming. Some fixed features are associated with factory-labeled buttons on your voice terminal. These button labels appear in bold type in the chart.
- **Custom Features** can be added or changed on voice terminals according to business and individual needs. As system administrator, you assign custom features coded with the symbol **[A]** in the chart. Those that individuals may assign to their own voice terminals are coded with the symbol **[I]**. Features that individuals may assign but that you may want to approve to meet the overall needs of your business are coded with the symbol **[AI]**. A page number under the name of each feature marked with an **[A]** tells you where to find instructions on assigning the feature.
- **Optional Features** require the purchase of additional equipment.

Fixed Features

Feature	Description
Call Pickup	<p>Allows a call coming in on one voice terminal to be answered from another voice terminal.</p> <ul style="list-style-type: none"> • This features allows someone's calls to be answered at a voice terminal in another office.
Call Waiting	<p>Signals you through your PBX/Centrex system if another call comes in on a PBX/Centrex line you are using. The MERLIN system gives you a brief tone through the voice terminal speaker and a green light flashes next to a line button if a call comes in on another line.</p>
Conference	<p>Lets you speak to two or more people at once depending on the limit set by your PBX/Centrex system. (With some PBX/Centrex systems, you may need to program Conference with a PBX/Centrex dial code.)</p>
Distinctive Ringing	<p>Provides different ringing patterns for outside, PBX/Centrex, and intercom calls, so you know what kind of calls you are receiving and can answer accordingly.</p>
Drop	<p>Disconnects the last line added to a conference call. (With some PBX/Centrex systems, you may need to program Drop with a PBX/Centrex dial code.)</p> <ul style="list-style-type: none"> • Use it to drop someone from a conference call, or to drop a busy or unanswered line when you are trying to set up a conference call.
Group Listening Speaker (See also Hands-Free Unit.)	<p>Allows others in the room to hear a caller.</p>
Hold (See also Music-on-Hold.) Automatic Hold Release Automatic Hold Reminder	<p>Keeps caller on the line while you answer a second call or attend to another matter. You always know which line you put on hold because the green light next to the line button flashes rapidly. The green lights next to the line buttons of calls that other voice terminals put on hold flash more slowly.</p> <p>Automatically frees the lines when a person on hold hangs up. (Your PBX/Centrex system may not have this feature; check your system's manuals.)</p> <ul style="list-style-type: none"> • An unused line is not kept busy unnecessarily. <p>Beeps once every minute to remind you that a caller is on hold.</p>
Intercom Intercom-Ring Intercom-Voice (See also Voice Announcement Disable.)	<p>Allows people in the MERLIN system to call each other without tying up PBX/Centrex lines. This feature also allows people to signal others by ringing or voice announcement without interrupting active calls.</p> <p>Announces an intercom call with a distinctive ring that people can recognize immediately.</p> <p>Lets you make short announcements to another MERLIN system voice terminal.</p>
Line Request	<p>Gives you a beep at your voice terminal when a busy line becomes available.</p>
Message Waiting Message (See also Send Message.)	<p>Alerts you with a green light beside your Message button when you have a message waiting.</p>
Monitor-on-Hold Speaker (See also Hands-Free Unit.)	<p>Frees you to do other work when you've been put on hold.</p> <ul style="list-style-type: none"> • You can hang up the handset until you hear the other person return to the call.

Fixed Features (continued)

Feature	Description
On-Hook Dialing Speaker (See also Hands-Free Unit.)	Enables you to dial outside or intercom calls without lifting the handset.
Recall	Provides a switchhook flash (brief press of the switchhook) to access PBX/Centrex features. In the MERLIN system, briefly depressing the switchhook only disconnects calls — it does not provide access to features.
Ringing Line Selection	Automatically selects the ringing line when a call comes in. <ul style="list-style-type: none">• You can answer a call without touching any buttons.
Send Message	Enables an attendant to notify someone that a message is waiting by turning on that person's Message light.
Transfer	Passes outside calls to any MERLIN system voice terminal or PBX/Centrex extension. (With some PBX/Centrex systems, you may need to program Transfer with a PBX/Centrex dial code.)
Voice Terminal Programming	Makes it possible to program any voice terminal with custom features according to business and individual needs.
Voice Terminal Testing	Verifies whether all lights and ringers are working when you slide the T/P switch on the left side of the voice terminal to <i>T</i> .
Volume Control	Adjusts the sound level of a voice terminal's ring and speaker.

Custom Features

Feature*	Description
Auto Intercom [I]	Program buttons on voice terminals for one-touch dialing of frequently called intercom numbers.
Automatic Line Selection (See page 30.) [AL]	Automatically selects a free line when you lift the handset to make a call. Anyone can program a voice terminal to select lines in a specific order.
Call Coverage (See page 25.) [AL] Primary Coverage Secondary Coverage	<p>Allows people to cover calls for others with whom they do not share lines. The system administrator must determine who can cover for whom.</p> <ul style="list-style-type: none"> • Voice terminals may be programmed for either primary or secondary coverage with immediate, delayed, or no ring. • One person can cover as many as five telephones. <p>Assigned to someone who screens another person's calls or answers calls when that person is away.</p> <ul style="list-style-type: none"> • A secretary can answer all calls to a manager's voice terminal. <p>Assigned to someone who provides a second backup for a covered voice terminal. Calls coming in on voice terminals assigned secondary coverage automatically ring after a delay.</p> <ul style="list-style-type: none"> • A backup secretary can cover calls for a primary attendant who is out to lunch.
Call Restriction (See page 20.) [A]	Enables administrator to adjust any voice terminal for call restriction if necessary. You can restrict voice terminals to only intercom or PBX/Centrex extension calls through your MERLIN system. Assign outward call restrictions through your PBX/Centrex system.
Do Not Disturb [I]	Prevents the voice terminal from ringing whenever you activate this feature. While Do Not Disturb is in effect, intercom callers get a busy signal and outside and PBX/Centrex calls ring at attendant consoles and any voice terminals covering for or assigned to that line.
Intercom Conference [I]	Allows you to include other people in your conference calls on their intercom lines. In addition to yourself, you can include up to two people on intercom lines and two people on outside lines. If you program a button for Intercom Conference, you must also program a button for intercom Drop.
Intercom Drop [I]	Allows you to disconnect a line in an Intercom Conference if the line is busy, no one answers, or you want to remove someone from the conference.
Last Number Redial [I]	Allows you to store the last number you dialed. (If your PBX/Centrex system does not return a dial tone immediately after dialing an outside line access number, this feature may not work properly.)
Manual Signaling [I]	Program a button so that touching it causes a beep at another voice terminal.
	<ul style="list-style-type: none"> • Use the button to signal another person.

* [A] means that the administrator assigns the feature.

[I] means that the individual can assign the feature.

[AL] means that an individual can assign the feature with the administrator's approval.

Custom Features (continued)

Feature*	Description
Outside Auto Dial [I]	Provides one-touch dialing of an outside number or PBX/Centrex extension.
Personalized Ring (See page 41.) [I]	Makes it possible to select one of eight ringing sounds for an individual voice terminal. <ul style="list-style-type: none"> • With this feature, people who work close to one another can distinguish the ringing of their own voice terminals from that of others.
Personal Speed Dial (See page 38.) [I]	For 5- and 10-button voice terminals only. Stores frequently dialed outside numbers. Each person can have a separate set of stored numbers. <ul style="list-style-type: none"> • Simplifies the dialing of frequently called numbers for employees whose voice terminals have no room for Outside Auto Dial buttons.
Privacy [I]	Ensures that calls are confidential by preventing others from joining calls on a shared line. This feature is automatic on intercom calls.
Programmable Line Ringing (See page 31.) [AI] Ring Option Override	Makes it possible to program individual outside and covered lines on a voice terminal to ring immediately, after a delay, or not at all on incoming calls. Causes all incoming calls to ring immediately at the voice terminal that activates this feature even on lines programmed for delayed ring or no ring. <ul style="list-style-type: none"> • Allows call coverage after hours by one person.
Programmable Shift Button (See page 37.) [AI]	For 34-button voice terminals only. Increases feature capacity by allowing you to program two features on each button to the right of the dial pad. The Programmable Shift feature must be programmed onto a button above the dial pad.
Saved Number Redial [I]	Stores a dialed number for later redialing. You can redial the number after making other calls by touching Saved Number again. (If the PBX/Centrex system does not return a dial tone immediately after dialing your outside line access number, this feature may not work properly.)
Speed Dial Access Button (See page 38.) [I]	Gives 5- and 10-button voice terminals the ability to store many telephone numbers with a limited number of line buttons. These numbers are accessed using Last Number Redial and Saved Number Redial buttons and 24-digit Personal Speed Dial codes.
Touch-Tone Enable [I]	Generates Touct-Tone signals on rotary lines. <ul style="list-style-type: none"> • People whose voice terminals have rotary lines can access alternate long distance services, banking-by-phone, credit card authorization, and other electronic services that require Touch-Tone dialing.

* [A] means that the administrator assigns the feature.

[I] means that the individual can assign the feature.

[AI] means that an individual can assign the feature with the administrator's approval.

Custom Features (continued)

Feature*	Description
Touch-Tone/Rotary Option (See page 19.) [A]	Makes it possible for the MERLIN system to work with either Touch-Tone or rotary lines, or both. <ul style="list-style-type: none">• Provides system flexibility — some voice terminals can be connected to Touch-Tone lines, others to rotary lines.
Voice Announcement Disable (See page 42.) [AI]	Blocks intercom voice announcements and makes voice terminals ring automatically on intercom calls. <ul style="list-style-type: none">• People can choose not to be interrupted by voice announcements.

* [A] means that the administrator assigns the feature.

[I] means that the individual can assign the feature.

[AI] means that an individual can assign the feature with the administrator's approval.

Optional Features

Feature	Description
<p>Loudspeaker Page</p> <p>Required equipment:</p> <ul style="list-style-type: none">• Services Module in control unit• Loudspeaker paging system	<p>Makes it possible to page others on a loudspeaker system with up to three zones that can be paged individually or together. Your business must provide the loudspeaker paging system. If your PBX/Centrex system already has a loudspeaker system, you access it using the procedures found in your PBX/Centrex user's guide.</p>
<p>Music-on-Hold</p> <p>Required equipment:</p> <ul style="list-style-type: none">• Services Module in control unit• Music source	<p>Provides music to callers put on hold. Your business must provide the music source, such as a tape player or FM radio.</p>
<p>Power Failure Transfer Service</p> <p>Required equipment:</p> <ul style="list-style-type: none">• Services Module in control unit	<p>Connects up to four basic telephones for use as backup during commercial power outage. The system automatically switches service to these telephones if power fails.</p>

Appendix: System and Voice Terminal Configuration Forms

This Appendix contains the forms that you need to administer your system. The System and Voice Terminal Configuration Forms make it possible for you to keep a record of your system and voice terminal configurations.

This brief guide will help you decide how to set up your MERLIN communications system (Models 1030 and 3070 with Feature Module 3) to satisfy the needs of your business. Read through this guide and answer the numbered questions. Boxed instructions will help you fill out a System Configuration Form (pages 61 and 62) and one Voice Terminal Configuration Form (pages 63 and 64) for each voice terminal in your system. Use these forms, together with the administration manual, to customize your MERLIN system.

SYSTEM OPTIONS

The following questions help you fill out the System Configuration Form on pages 61 and 62. Complete this form before filling out any Voice Terminal Configuration Forms.

1. How many attendant consoles did you order (to be heavily used for answering and transferring calls coming into your business, or for monitoring call traffic)? _____

A.

Attendant Configuration

On the System Configuration Form, check the boxes under “Attendant Configuration” for intercom numbers of any voice terminals (in addition to intercom 10) to be used as attendant voice terminals. The system supports a maximum of seven such positions in addition to intercom number 10.

B.

Listing Line Numbers and User Names

Fill in the names of users in the first column of the System Configuration Form. Use intercom number 10 for your primary attendant (or receptionist). If you have additional attendants, assign intercom numbers 11 through 17 to them. Fill in the primary line number for each person.

C.

Rotary Lines

If you have any rotary outside lines, circle the “r” next to each of these lines on the System Configuration Form. Call your local telephone company if you don’t know what type of lines you have.

2. Does your PBX/Centrex system offer holding of calls, transferring of calls, conferencing of calls, or dropping of calls from conferences? If so, what procedures must you follow to perform these operations? For example, many systems allow you to hold a call by pressing the switchhook (a switchhook flash), while others require a switchhook flash followed by a dialed code (such as * 2).

D.

Special Codes for Hold, Transfer, Conference, and Drop

If your PBX/Centrex system offers Hold, Transfer, Conference, or Drop but requires that you dial codes (other than a single switchhook flash) to use these features, record the complete dial sequence on the System Configuration Form in the blanks for these features. Indicate digits, switchhook flashes (with “r”), and pauses (with “p”) for each available feature.

VOICE TERMINAL OPTIONS

Now that you have completed the System Configuration Form, you can fill out Voice Terminal Configuration Forms for each voice terminal in your system. You may wish to begin by creating a system directory and planning out which intercom number and which type of voice terminal each person will use. Then, complete the following section for each voice terminal in your system. Be sure to select the appropriate form (attendant or non-attendant) for the voice terminal you are configuring.

E.

Beginning a Voice Terminal Configuration Form

At the top of the Voice Terminal Configuration Form, fill in the intercom number and the user name, as assigned on the System Configuration Form. Assign intercom number 10 to your primary attendant or receptionist. Check the appropriate boxes to indicate voice terminal size, stand type, and any accessories needed for this terminal. Group basic telephones together for example, reserve intercom numbers 30 through 39 for basic telephones, and use other intercom numbers for regular MERLIN system voice terminals.

F.

Assigning Lines (Attendant Positions)

If this is not an attendant's voice terminal, skip to box G. If this is an attendant's voice terminal, write the line number for each line that this voice terminal will access on the appropriate button. On the System Configuration Form you associated each line with a control unit jack number. These control unit jack numbers appear on the buttons on this form to show you where each line will initially appear. If you have a large system, note that jack numbers G0-J4 do not appear on any buttons. If your system has more than 30 lines, replace some of the initial 30 lines with the last 20 lines on one or more of the attendant voice terminals. For example, for a 40-line system, replace lines E0-F4 with lines G0-H4 on at least one attendant voice terminal. A maximum of 30 lines may appear on an attendant voice terminal. Now skip to box H.

G.

Assigning Lines (Non-attendant Positions)

If this is not an attendant's voice terminal, write the PBX/Centrex extension number for this person's primary line in the button labeled 1. In the buttons labeled 2, 3, 4, etc., fill in the extension numbers of any secondary lines to be used. Do not skip numbered boxes. You can assign up to 12 secondary lines to each non-attendant voice terminal, although you need a 34-button deluxe voice terminal to support more than one primary and seven secondary lines.

H.

Covering Calls for Others

If the person using this voice terminal needs to cover inside calls or to cover outside calls coming in on a line that doesn't appear on the voice terminal, he or she needs a Cover button. On the Voice Terminal Configuration Form, find a button that is not already a line or intercom button. Use only buttons with lights. Write in the button the word "Cover" and the name and intercom number of the person whose calls are to be covered. If there are no buttons available, check the initial features assignment diagram (page 29) and replace a less-needed feature button with a Cover button. Also assign an Auto Intercom button for each person to be covered and label it with the appropriate name. These buttons should also have lights.

I.

Having Others Cover Calls for This Voice Terminal

If the person using this voice terminal needs to have other people cover or pick up his or her calls, fill in the bottom left corner of the Voice Terminal Configuration Form by writing the intercom numbers of people who will have Cover buttons for this terminal. If people without access to cover buttons or to lines for this voice terminal will pick up calls on its lines, fill in a Y in the bottom left corner of the page, next to "Are other people permitted to pick up calls for this voice terminal?"

J.

Automatic Answering

If this voice terminal has a Hands-Free Unit, write "Auto Answer-Intercom" on an available button with lights on the Voice Terminal Configuration Form. If this voice terminal has an Automatic Multipurpose Adapter, write "Auto Answer-Outside" on an available button with lights on the form.

K.

Other Features Assigned to Buttons

Review the appropriate initial feature assignments diagram on page 29. Any buttons that have not been assigned lines or special features will have these initial feature assignments. Copy all feature names from the diagram onto buttons that are still blank. Leave Outside Auto Dial buttons blank.

L.

Line Ringing

Decide which lines should ring immediately at this person's voice terminal and which lines should ring after a delay (so that calls ring only if someone who usually answers is unavailable). Indicate immediate ringing by writing "R" on the blanks to the left of the appropriate line button; indicate delayed ringing by writing a "D" beside the appropriate line buttons. Similarly, indicate whether Cover buttons should ring immediately when a call comes in ("R"), after a three-ring delay ("D"), or after a six-ring delay ("DD"). If you set a line not to ring, do not fill in the blank. Calls transferred to this voice terminal on this line will still ring.

M.

Calling Restrictions

If you plan to restrict this voice terminal from making toll (long distance) calls, check "Toll Restriction" on the Voice Terminal Configuration Form. If you plan to restrict the voice terminal from making calls outside the MERLIN system, check "Outside MERLIN System Call Restriction" on the form.

N.

Automatic Line Selection

If lines don't appear on this voice terminal in the order that they are most likely to be used, list the order of use at the bottom of the Voice Terminal Configuration Form under the heading "Automatic Line Selection."

O.

Now return to box E and repeat this process until you have filled out one Voice Terminal Configuration Form for each voice terminal in your system.

System Configuration Form Model 1030 and 3070 with Feature Module 3

Attendant Configuration:

11 12 13 14
 15 16 17

PBX/Centrex Dial Codes for

Fixed Features:

Transfer _____
 Conference _____
 Drop _____

Name of Person Using Telephone	Intercom Number	Control Unit Jack Number	Primary PBX/Centrex Line Number	Circle if Rotary
	10	A0		r
	11	A1		r
	12	A2		r
	13	A3		r
	14	A4		r
	15	B0		r
	16	B1		r
	17	B2		r
	18	B3		r
	19	B4		r
	20	C0		r
	21	C1		r
	22	C2		r
	23	C3		r
	24	C4		r
	25	D0		r
	26	D1		r
	27	D2		r
	28	D3		r
	29	D4		r
	30	E0		r
	31	E1		r
	32	E2		r
	33	E3		r
	34	E4		r
	35	F0		r
	36	F1		r
	37	F2		r
	38	F3		r
	39	F4		r
	40	G0		r
	41	G1		r
	42	G2		r

System Configuration Form (continued)

Name of Person Using Telephone	Intercom Number	Control Unit Jack Number	Primary PBX/Centrex Line Number	Circle if Rotary
	43	G3		r
	44	G4		r
	45	H0		r
	46	H1		r
	47	H2		r
	48	H3		r
	49	H4		r
	50	I0		r
	51	I1		r
	52	I2		r
	53	I3		r
	54	I4		r
	55	J0		r
	56	J1		r
	57	J2		r
	58	J3		r
	59	J4		r

Voice Terminal Configuration Form Models 1030 and 3070 with Feature Mode 3 Attendant Consoles

Intercom # _____ Identification _____

Stand Type:

- Wall
- Plastic
- Fixed
- Desk
- Metal
- Adjustable

Accessories:

- Headset
- Headset Adapter
- Hands-Free Unit
- Manual Multipurpose Adapter
- Automatic Multipurpose Adapter
- Extra Long Cord
- Acoustic Coupler Adapter
- Hearing-Impaired Handset
- Push-to-Listen Handset
- Voice Terminal Power Supply
- Attendant Intercom Selector

34-Button

▶ <input type="checkbox"/> A2	▶ <input type="checkbox"/> B2	▶ <input type="checkbox"/> B3	▶ <input type="checkbox"/> D4
▶ <input type="checkbox"/> A1	▶ <input type="checkbox"/> B1	▶ <input type="checkbox"/> B4	▶ <input type="checkbox"/> E0
▶ <input type="checkbox"/> A0	▶ <input type="checkbox"/> B0	▶ <input type="checkbox"/> C0	▶ <input type="checkbox"/> E1
▶ <input type="checkbox"/> Intercom Voice	▶ <input type="checkbox"/> A4	▶ <input type="checkbox"/> C1	▶ <input type="checkbox"/> E2
▶ <input type="checkbox"/> Intercom Ring	▶ <input type="checkbox"/> A3	▶ <input type="checkbox"/> C2	▶ <input type="checkbox"/> E3
		▶ <input type="checkbox"/> C3	▶ <input type="checkbox"/> E4
		▶ <input type="checkbox"/> C4	▶ <input type="checkbox"/> F0
		▶ <input type="checkbox"/> D0	▶ <input type="checkbox"/> F1
		▶ <input type="checkbox"/> D1	▶ <input type="checkbox"/> F2
		▶ <input type="checkbox"/> D2	▶ <input type="checkbox"/> F3
		▶ <input type="checkbox"/>	▶ <input type="checkbox"/> F4
		▶ <input type="checkbox"/>	▶ <input type="checkbox"/>

Calling Restriction:
 Toll Call Restriction
 Outside MERLIN System Call Restriction

Automatic Line Selection: _____

Are other people permitted to pick up calls for this voice terminal? (Y/N) _____

Calls for this voice terminal allowed to be covered by: (Intercom numbers) _____

Voice Terminal Configuration Form Models 1030 and 3070 with Feature Module 3 Non-attendant Voice Terminals

Intercom # _____ Identification _____

Voice Terminal Size:

- 5-Button
- 10-Button
- 34-Button
- 34-Button Deluxe
- Basic Touch-Tone or Rotary Telephone

Stand Type:

- Wall
- Plastic
- Fixed
- Desk
- Metal
- Adjustable

Accessories:

- Headset
- Headset Adapter
- Hands-Free Unit
- Manual Multipurpose Adapter
- Automatic Multipurpose Adapter
- Extra Long Cord
- Acoustic Coupler Adapter
- Hearing-Impaired Handset
- Push-to-Listen Handset
- Voice Terminal Power Supply
- Attendant Intercom Selector

34-Button

10-Button

5-Button

<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">3</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">8</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">9</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>
<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">2</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">7</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">10</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>
<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">1</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">6</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">11</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>
<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">Intercom Voice</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">5</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">12</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>
<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">Intercom Ring</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">4</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;">13</div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>
		<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>
		<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>
		<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>
		<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>	<input type="checkbox"/> <div style="border: 1px solid black; padding: 2px; display: inline-block;"></div>

Calling Restriction:

- Toll Call Restriction
- Outside MERLIN System Call Restriction

Automatic Line Selection:

Are other people permitted to pick up calls for this voice terminal? (Y/N) _____

Calls for this voice terminal allowed to be covered by:
(Intercom numbers) _____

Index

A

- Administration Mode, 16
 - Button Labels, 10, 15
 - Entering, 16
 - Leaving, 16
- Administrator/Attendant Console, 3, 10
- Attendant Consoles
 - Special Information about, 43
- Attendant Intercom Selector, 10, 11, 43
- Auto Intercom Buttons, 10, 36, 43, 52
- Automatic Line Selection, 52
 - Assigning, 30

B

- Basic Administration, 17
- Basic Telephone Module, 7, 11, 43
- Blocking the System from Incoming Calls, 27

C

- Call Coverage Permissions, 52
 - Assigning, 25
- Call Pickup Permissions, 50
 - Assigning, 26
- Call Restrictions, 20, 52
 - Assigning, 21
- Conference, 23, 50
- Control Unit, 3, 6
 - Setting, 18
- Copy, 21
- Cover, 31, 43
 - Assigning, 32
 - Primary Coverage, 32, 37, 52
 - Secondary Coverage, 33, 37, 52
- Custom Features, 52 - 54
- Customizing with Additional System Options, 24 - 27

D

- Diagnostics Module, 7
- Drop, 23, 50

E

- Entering Administration Mode, 16

F

- 5-Button Voice Terminals, 20
 - Special Information About, 48
- Feature Module 3, 7
 - Attendant/Administrator Option, 7
 - Normal/Attendant Options, 7, 18
- Feature Programming Chart, 36, 37
- Fixed Feature Buttons
 - Administering, 23
- Fixed Features, 50, 51

H

- Hands-Free Unit, 11, 46
- Headset and Headset Adapters, 11
- Hold, 50

I

- Initial Feature Assignments
 - Attendant Consoles, 44
 - Attendant Consoles with Selector, 45
 - Non-attendant Voice Terminals, 29
- Intercom Buttons
 - Intercom-Ring, 50
 - Intercom-Voice, 50

L

- Labels
 - Administration Mode Button, 10, 15
- Last Number Redial, 36, 46, 47, 48, 52
- Leaving Administration Mode, 16
- Line Module, 7, 20
- Line Ringing, 31
 - Delayed Ring, 31, 32
 - Immediate Ring, 31, 32
 - No Ring, 31, 32, 43
- Lines, 20
 - Primary, 20
 - Secondary, 20
- Loudspeaker Paging System, 18, 37, 43, 46

M

- Manual Signaling, 37, 52
- Message, 37, 50
- Message Waiting, 50
- Model 1030 Control Unit, 6, 7
 - Diagram, 6
- Model 3070 Control Unit, 6, 8
 - Diagram, 8
- Multipurpose Adapters, 11
- Music-on-Hold, 18

O

- Office Priorities
 - Programming Voice Terminals for, 28 - 33
- Optional Equipment, 11

P

- PBX/Centrex Extensions
 - Assigning to Line Buttons, 22
- Personalized Ring, 53
 - Selecting, 41
- Personal Priorities
 - Programming Voice Terminals for, 34 - 42
- Personal Speed Dial Codes, 47, 48, 53
 - Assigning to 5- and 10-Button Voice Terminals, 38
- Power Module, 7
- Preparing to Administer Your System, 14 - 16
- Primary Lines
 - Assigning, 20
- Processor Module, 7
- Programmable Line Ringing, 53
 - Assigning, 31

Q

Quick Reference Guide to Administration
Procedures, 67 - 68

R

Recall, 4, 39, 51
Ring Option Override, 31, 37, 53
Rotary Dialing
Specifying, 19

S

Saved Number Redial, 36, 46, 47, 48, 53
Secondary Lines
Assigning, 20
Selecting a Personalized Ring, 41
Send Message, 51
Services Module, 7, 9, 18, 55
Setting Your Console Unit, 18
Shift Buttons, 10
Speaker, 50, 51
Special Characters
Using in Programmed Dialing Sequences, 39
Speed Dial Access, 36, 38, 47, 48, 53
Switches, 7, 9, 18
System Configuration Form, 15, 56, 57, 61, 62

T

10-Button Voice Terminals, 20
Special Information about, 47
34-Button Voice Terminals, 10
Special Information about, 46
Touch-Tone Dialing
Specifying, 19
Touch-Tone Enable, 37, 54
Touch-Tone/Rotary Option, 19, 54
T/P (Test/Program) Switch, 16, 51
Transfer, 23, 51

U

Using Special Characters in Programmed Dialing
Sequences, 39

V

Voice Announcement Disable, 42, 54
Voice Terminal Configuration Form, 15, 56, 58
Attendant, 63
Non-attendant, 64
Voice Terminal Module, 7
Volume Control, 51

Quick Reference Guide to Administration Procedures

This chart summarizes the administrative procedures described on pages 17 through 27. For more information about a procedure, refer to the page listed.

Before you perform any of these procedures, enter administration mode by following the steps below.

- Set switch A on the Processor Module in the control unit to *Administer* (down).
- Insert the administration mode button labels (see the back of this manual) in the administrator/attendant console.
- Slide the T/P switch on the left side of the console to *P*.

When you finish administering your system, leave administration mode by following the steps below.

- Slide the T/P switch to the center position.
- Set switch A on the Processor Module to *Attendant* (up).
- Remove the administration mode button labels from the console and insert the regular call-handling labels used by the attendant.

Procedure	Touch	Then
<p>PERFORM BASIC ADMINISTRATION</p> <p>Assign or remove lines on individual voice terminals.</p> <p>(See page 20.)</p>	Adm Tel	<ul style="list-style-type: none"> • Dial the voice terminal's intercom number. • Touch the line buttons. <p><i>Steady green on = line assigned</i> <i>Green off = line removed</i></p>
<p>Specify Touch-Tone or rotary signaling for each line in your system.</p> <p>(See page 19.)</p>	Adm Opt	<ul style="list-style-type: none"> • Dial 3. • Touch the line buttons. <p><i>Steady green on = Touch-Tone signaling</i> <i>Green off = rotary signaling</i></p>
<p>Assign PBX/Centrex extensions to line buttons. (Attendant consoles only)</p> <p>(See page 22.)</p>	Adm Opt	<ul style="list-style-type: none"> • Dial 1. • Touch the line button. • Dial the PBX/Centrex extension.
<p>Program PBX/Centrex dial sequences onto fixed feature buttons.</p> <p>(See page 23.)</p>	Adm Opt	<ul style="list-style-type: none"> • Dial 2. • Touch the fixed feature button. • Dial the PBX/Centrex dial sequence.
<p>Assign call restrictions to voice terminals.</p> <p>(See page 20.)</p>	Adm Tel	<ul style="list-style-type: none"> • Touch Call Rstr. <p><i>Steady green on = all calls permitted</i> <i>Flashing green = PBX/Centrex extensions and MERLIN intercom calls only</i> <i>Green off = MERLIN intercom calls only</i></p>

Quick Reference Guide to Administration Procedures (continued)





Procedure	Touch	Then
CUSTOMIZE WITH ADDITIONAL SYSTEM OPTIONS		
Copy the same secondary line assignments and call restrictions from one voice terminal to another voice terminal. (See page 21.)	Adm Tel	<ul style="list-style-type: none"> • Touch the Auto Intercom button of the unassigned voice terminal. • Touch Copy. • Touch the Auto Intercom button of the voice terminal whose assignment you want to copy.
Block all incoming calls before turning off control unit to make hardware changes. (See page 27.)	Adm Opt	<ul style="list-style-type: none"> • Dial 0.
Assign Call Coverage permissions. (See page 25.)	Adm Opt	<ul style="list-style-type: none"> • Dial 5. • Dial the intercom number of the voice terminal whose calls you want covered. • Touch the line buttons. <ul style="list-style-type: none"> <i>Steady green on</i> = <i>the voice terminals associated with these primary lines can cover calls for this intercom number</i> <i>Green off</i> = <i>the voice terminals associated with these primary lines cannot cover calls for this intercom number</i>
Assign Call Pickup permissions. (See page 26.)	Adm Opt	<ul style="list-style-type: none"> • Dial 4. • Touch the line buttons. <ul style="list-style-type: none"> <i>Steady green on</i> = <i>calls can be picked up</i> <i>Green off</i> = <i>calls cannot be picked up</i>

SLOT 1

SLOT 2


SLOT 3

SLOT 4



ADMINISTRATION MODE BUTTON LABELS FOR ADMINISTRATOR/ATTENDANT CONSOLE
(SYSTEMS WITH THIRTY LINES OR FEWER)


How to Use Label Strips



1. Using typewriter or other writing utensil, **label each line button.***



2. **Crease** perforated edges first, **then tear out** each label strip.



3. **Insert label strips** into the slots on administrator/attendant console. Numbers on the tabs at the top of each strip indicate the correct slot for the strip. Slot 1 is on the far left; slot 4 on the far right.

* Note the control unit line module jack number (A0-F4) printed on the line button labels. Label each button with the number of the outside line plugged into the control unit jack whose number is printed on the button label.

Call Rstr

Copy

SLOT 1

SLOT 2

SLOT 3

If you have a large attendant console, use the button labels on the previous page in addition to the button labels on this page.

Insert these button labels in your Attendant Intercom Selector.

G0	I0	
G1	I1	
G2	I2	
G3	I3	
G4	I4	
H0	J0	
H1	J1	
H2	J2	
H3	J3	
H4	J4	
10 20 30	40 50 60	70-80-90

ADMINISTRATION MODE BUTTON LABELS FOR ATTENDANT INTERCOM SELECTOR
(SYSTEMS WITH MORE THAN THIRTY LINES)

* Note the control unit line module jack number (G0-J4) printed on the line button labels. Label each button with the number of the outside line plugged into the control unit jack whose number is printed on the label.

999-506-138-IS

